



12
3
 D7 / D 12
 12/87

12 3		12/87						
Nr.	Teile-Nummer	Symbol	Benennung	D 7	D 12			Bemerkung
1	a 12 52 1 334 160		Halteblech / Retaining plate / Tôle de retenue / Fästplåt	1				
2	12 32 1 334 009		Impulsgeber / Pulse transmitter / Générateur d'impulsions / Impulsgivare	1	1			
3	12 32 1 334 008		Reglerschalter / Regulator cutout / Conjoncteur-disjoncteur / Regleringsrelä	1	1			
4	07 11 9913 082		6 KT SHR M4 × 10	3	1			
5	07 11 9931 027		A 4.3 Scheibe / Washer / Rondelle / Bricka	7	6			
6	07 11 9922 028		6 KT MU M4	7	6			
7	07 11 9913 084		6 KT SHR M4 × 12	2	2			
8	61 13 1331 901		25 A Sicherungsautomat / Automatic fuse / Coupe-circuit automatique / Automatsäkring	1	1			
9	07 11 9913 089		6 KT SHR M4 × 16	2	2			
10	61 13 1243 092		Kabelband / Cable strip / Ruban de câbles / Kabelband	1	1			
11	a 61 31 1 373 586		Relais / Relay / Relais / Relä	1	1			
12	12 52 1 329 968		Gummitülle / Rubber grommet / Douille en caoutch. / Gummihatt	2	1			
13	a 12 51 1 334 045		Kabelbaum / Cable harness / Faisceau de câble / Kabelbom	1	1			
14	12 31 1 334 077		Vollisoliert-Stator / Stator with solid dielectric / Stator entièrement isolé / Helisolerad stator	1				