



62
2
 D7 / D12
 12/97

62 2		12/97																			
Nr.	Teile-Nummer	Symbol	Benennung													D7		D12		Bemerkung	
1	b 62 11 133968		kpl. Instrumententafel / Instrument panel / Tableau des instruments / Instrumenttavla													1	1				
2	07 11 9902520		BL SHR B 4,2													4	4				
3	b 61 32 1331962		Zündschlüssel-Rohling / Ignition key blank / Clé de contact-brute / Råamne för tändnyckel													X	X				
4	b 61 13 1331916		BA Feinsicherung / Precision fuse / Fusible fin / Finsäkring													1	1				
5	b 61 11 1331957		Kabelbaum-Instrumente / Cable harness-instruments / Faisceau de câbles-instruments / Kabelstam-instrument													1	1				
6	b 62 11 1333970		Instrumententafel / Instrument panel / Tableau des instruments / Instrumenttavla													1	1				
7	62 148 684 136		Kontrollleuchte – rot / Telltale lamp – red / Lampe témoin – rouge / Kontrolllampe – röd													2	2				
8	62 148 680 131		Lampenfassung / Light socket / Pied d'ampoule / Lamphållare													2	2				
9	07 11 9978256		HL 12 V 4 W Glühlampe / Bulb / Ampoule / Glödlampa													2	2				
10	b 61 32 1331960		kpl. Zündanlasschalter / Ignition-starter switch / Commutateur de demarreur / Tändstartkontakt													1	1				
11	b 61 32 1331971		6KT MU													1	1				
12	b 61 32 1331972		Schutzkappe / Protection cap / Capot de protection / Skyddskåpa													1	1				
13	b 61 13 1328974		Sicherungshalter / Fuse holder / Porte-fusible / Säkringshållare													1	1				
14	b 62 13 1333924		Ø 60 Blinddeckel / Cover / Covercle / Lock													1	1				
15	b 62 13 1333925		Ø 80 dito													1	1				
16	b 1251 1333912		3mtr. Kabelbaum / Cable harness / Harnais de câbles / Kabelbom													1	1				