



12
2

07 D12
12-87

12 2		12/87			D7	D12	Bemerkung
Nr.	Teile-Nummer	Symbol	Benennung				
1	a 12 52 1 333 917		Halteblech / Retaining plate / Tôle de retenue / Fästplåt		1	1	
2	12 32 1 334 009		Impulsgeber / Pulse transmitter / Générateur d'impulsions / Impulszivare		1	1	
3	12 32 1 334 008		Reglerschalter / Regulator cutout / Conjoncteur-disjoncteur / Regleringsrelä		1	1	
4	07 11 9928 423		SK SHR M 4 × 12		1	1	
5	b 07 11 9913 084		6 KT SHR M 4 × 12		2	2	
6	07 11 9922 028		6 KT MUM 4		7	7	
7	07 11 9931 027		A 4,3 Scheibe / Washer / Rondelle / Bricka		7	7	
8	b 61 13 1 331 901		25 A Sicherungsautomat / Automatic fuse / Coupe-circuit automatique / Automatsäkring		2	2	
9	07 11 9913 089		6 KT SHR M 4 × 16		4	4	
10	b 12 52 1 329 968		Gummitülle / Rubber grommet / Douille en caoutch. / Gummihatt		1	1	
11	61 13 1 243 092		Kabelband / Cable strip / Ruban de câbles / Kabelband		2	2	
12	a 12 62 1 331 929		70° Temperaturschalter / Temperature switch / Thermostat / Temperaturbrytare		1	1	
13	a 12 51 1 333 952		Kabelbaum-Motor / Cable harness, motor / Harnais de câbles, moteur / Kabelbom-motor		1	1	
14	12 31 1 334 007 12 31 1 334 077		Stator / Stator / Stator / Stator dito		1	1	